



Sensible. Sound.
Solutions.



The mark of
responsible forestry

440 SoundBarrier®
and N.C.F.R.® Homasote®



**Wall
Applications**

Table of Contents

APPLICATION	PAGE
Packaging, Storage – Interior and Wall Panel Applications	1
1-A) Decoupled Wall System – Enhanced Sound Attenuation	2
1-B) Staggered Stud Wall Construction – STC 53	2
1-C) Double Wall Construction – STC 60	2
1-D) 440 SoundBarrier to Masonry Wall	3
2-A) Fabric-Wrapped 440 SoundBarrier – To Wood or Metal Framing	3
2-B) Fabric-Wrapped 440 SoundBarrier – To Masonry Walls	3
2-C) Fabric-Wrapped 440 SoundBarrier – To Finished Walls	3
2-D) Complete Instructions for Metal Frame Clips	3
440 SoundBarrier Specifications	4

Packaging, Storage and Protection

All Homasote products having a maximum 4' width are packaged in plastic covered units. However, all materials should be stored above grade on wooden pallets and covered by waterproof tarpaulins. Packaging material is not intended for exterior job site protection.

Interior Applications

General Requirements: Temperature and humidity conditions closely approximating those which will exist when building is occupied shall be maintained before, during, and after the application of panels. **Installation shall not be made when building is excessively dry, cold, hot or damp.** All panels shall be removed from plastic covered units and separated not less than 24 hours prior to installation to allow material to acclimate.

Applications as a Wall Panel



440 SoundBarrier® panels should be applied vertically to the framing with blocking or plates at top and bottom of panel. **All edges of panel must fall on framing at all times. Framing for 1/2"-thick panels must not exceed 16" o.c. Framing for 5/8"-and 3/4"-thick panels must not exceed 24" o.c. During installation, all panels must be fastened leaving a 1/8" expansion gap between sheets and 1/4" expansion gaps at floor, ceiling, and around window and door frames, etc. Do not fill or tape panel joints. If left exposed 440 SoundBarrier may be painted with a quality latex based primer and finish paint applied by brush and/or roller. DO NOT SPRAY PANELS.**

1) Installation for use as a Sound Control Panel

(behind gypsum wallboard or other paneling)

To reduce sound intensity, attention must be given to wall openings for conduits, pipes, ducts, electrical junction boxes and any other devices. Avoid back-to-back coincidence of openings on opposite sides of a wall. When the purpose of the openings has been completed, open spaces must be packed with acoustical insulation, or otherwise caulked, and sealed with a good grade acoustical sealant to assure an airtight closure.


Doorstops should be gasketed and dropseals installed at door bottoms. **Do not caulk between 440 SoundBarrier® panels.** This space allows for the natural expansion and contraction of the 440 SoundBarrier panels. 440 SoundBarrier panels must be installed vertically. After application of gypsum wallboard, the entire floor-ceiling wall perimeter must be caulked with acoustical sealant.

	Insulation	16" on Center Spacing	24" on Center Spacing
WOOD			
 <p>5/8" Type C Wallboard 1/2" 440 SoundBarrier 2" x 4" Wood 5/8" Type C Wallboard</p>	3" MW*	STC 53	STC 50
	3-1/2" FG*	STC 52	STC 50
STEEL			
 <p>5/8" Type X Gypsum Wallboard 1/2" 440 SoundBarrier 3-5/8" 25ga Steel 5/8" Type X Gypsum Wallboard</p>	3" MW* <i>or</i> 3-1/2" FG*	STC 54	STC 55
1 Extra Layer 5/8" Type X Wallboard	3" MW* <i>or</i>	STC 58	
2 Extra Layers 5/8" Type X Wallboard	3-1/2" FG*		STC 59

*MW = Mineral Wool; FG = Fiberglass


1-A) Decoupled Wall System – Reduced Sound Transmission on Wood or Steel Studs

- 1) Apply 440 SoundBarrier panels vertically to framing on one side. Allow for expansion gaps as stated at the bottom of page 1. Using ring-shank nails or wood/metal drywall screws; attach 12" o.c. along edges and 24" o.c.



along all intermediate framing. Nails or screws should be of sufficient length to penetrate 3/4" into framing. Hold nails or screws 3/8" back from panel edges.

- 2) Apply 3/8" bead of adhesive to the 440 SoundBarrier that meets the specification APA AFG-OI (such as Liquid Nails or PL400) in single vertical serpentine beads that are in between the studs. Stagger gypsum wallboard so edges do not fall onto studs. Using rock-to-rock screws (#10 x 1-1/2" bugle head screws), secure gypsum wallboard directly to 440 SoundBarrier panels every 8" o.c. around panel edges and 12" o.c. on intermediate sections of panel. Do not fasten the gypsum wallboard into studs.




*Resilient channels or furring strips may also be installed over 440 SoundBarrier panels provided that the channels/strips are screwed through the 440 SoundBarrier into framing as per manufacturer's recommendations.

1-B) Staggered Stud Wall Construction - STC 53

- 1) Construct staggered stud wall using a 2" x 6" sole plate and 2" x 4"s placed 12" o.c. alternating from side to side, resulting in studs on 24" o.c. on each side.
- 2) Install 3 1/2" high fiber count sound batt insulation by weaving between the framing members. Rock wool (mineral wool) insulation is an optional material that can be installed in lieu of fiberglass insulation.
- 3) Apply 440 SoundBarrier panels following instructions in Section 1-A, Step 1.
- 4) Apply gypsum drywall following instructions in Section 1-A, Step 2.

STC 53 - Staggered Wood Stud Partition

Decoupled Wall System UL U340




1-C) Double Wall Construction - STC 60

- 1) Construct dual frame 2" x 4" placed 16" o.c. (24" O.C. not tested but should exceed STC-60)
- 2) Maintain a 1" dead air space separation between wall framing.
- 3) Install 3-1/2" high fiber count sound bat insulation in both sides of wall. Rock wool (mineral wool) insulation is an optional material that can be installed in lieu of fiberglass insulation.
- 4) Apply 440 SoundBarrier panels following instructions in section 1-A, Step 1.
- 5) Apply gypsum drywall following instructions in section 1-A, Step 2.

STC 60 - Double Wood Stud Partition

Decoupled Wall System UL V305



(24\"/>

1-D) To Masonry Walls

- 1) As per APA recommendations, install wood furring strips, not exceeding 16\"/>
- 2) Apply 440 SoundBarrier panels following instructions in section 2 of "1-A) To Wood or Metal Framing."
- 3) Install gypsum wallboard or other paneling over 440 SoundBarrier panels so panel joints are staggered and do not coincide. Follow gypsum wallboard manufacturer's installation recommendations.

2) Installation for use as a Fabric-Wrapped Panel

440 SoundBarrier panels have different textures on each side. One is a smoother linen texture and the other a rougher screen texture. Select the side to apply fabric that best suits your needs. Also notice that, due to the nature of the product, the surfaces of 440 SoundBarrier panels are not perfectly flat; determine the suitability of the panels as a substrate for your fabric prior to fabric application. (Apply fabric to a small sample, if necessary, to help make that determination). Lightly sanding the surface of the 440 SoundBarrier panels will help eliminate textures, inconsistencies and to aid fabric adhesion. Monolithic fabric installations are not recommended. *Homasote 440 PINnacle™ and N.C.F.R. PINnacle™ are fine-sanded panels also used as a substrate for fabric wrapping. Homasote also offers factory-wrapped interior panels. Call Homasote Company for details.*

2-A) Fabric-Wrapped 440 SoundBarrier To Wood or Metal Framing

- 1) Apply fabric to 440 SoundBarrier panels using adhesive recommended by fabric manufacturer for application to wood fiberboard. The fabric adhesive must be applied to the face of the panel in the proper amount to prevent bleed through. Wrap fabric and glue around edges and continue for 2\"/>
- 2) Lay panels flat for the necessary time to allow adhesive to fully set.
- 3) Apply a 3/8\"/>

- 4) Attach metal frame clips to long edges of 440 SoundBarrier panels every 12\"/>
- 5) Apply fabric-wrapped 440 SoundBarrier panels to adhesive and framing, with recommended expansion gaps as stated at the bottom of page 1, applying hand pressure from the center of panel out to the ceiling and floor where adhesive is located to insure positive contact. Screw panels 6\"/>

2-B) Fabric-Wrapped 440 SoundBarrier To Masonry Walls


- 1) As per APA recommendations, install wood furring strips to masonry walls, not exceeding 16\"/>
- 2) Follow instructions "2-A) Fabric-Wrapped 440 SoundBarrier To Wood or Metal Framing" for applying fabric wrapped 440 SoundBarrier panels.

2-C) Fabric-Wrapped 440 SoundBarrier To Finished Walls

Apply wall panels following instructions in "2-A) Fabric-Wrapped 440 SoundBarrier To Wood or Metal Framing". Apply adhesive to back of 440 SoundBarrier panels in 3/8\"/>

2-D) Complete Instructions For Metal Frame Clips*

- 1) Lay out back of panel by drawing lines at 16\"/>
- 2) Locate clips above the line on one side and below on the opposite side. (A staggered clip layout creates a tongue-and-groove panel joint). See diagram (right).
- 3) Seat the clips around the perimeter of the board as shown in the diagram. Do not damage panel edge. (Use 7 clips per side for a 4' x 8' panels).
- 4) Apply a 3/8\"/>



- 5) Position panels (with clips installed) on any wood or metal framing. Tighten the joint with a floor leverage tool. Screw or nail panels to floor and ceiling plates as per 440 SoundBarrier installation instructions. Use low-profile screws to secure one series of clips to wall stud. Stagger joints on opposite sides of the wall when possible.
- 6) The clips on the adjacent panel simply slide behind the fixed panel.

*Source: Cymax Systems, Inc.

440 SoundBarrier® SPECIFICATIONS

PART 1 GENERAL

1.1 Section Includes

- A. Sound-deadening acoustical wall systems.

1.2 References

- A. ASTM E 84– test method for surface burning characteristics of building materials.
- B. ASTM D 1037–test methods of evaluating properties of wood-base fiber and particle panel materials
- C. ASTM C209 – Standard Test Methods for Cellulosic Fiber Insulating Board.
- D. UL Category BXUV: Mineral & Fiber Boards UL 1-Hour Fire Resistance assemblies

1.3 Submittals

- A. Submit under provisions of section 01300.
- B. Product data: manufacturer's catalog data, detail sheets, and specifications.
- C. Quality assurance/control submittals:
 - 1. Manufacturer's installation instructions.

1.4 Quality Assurance

- A. Manufacturer's qualifications:
 - 1. Minimum 10 years experience in producing sound-deadening boards of the type specified herein.

1.5 Delivery, Storage, and Handling

- A. Deliver materials in manufacturer's original packages.
- B. Inspect the materials upon delivery to assure that specified products have been received.
- C. Report damaged material immediately to the delivering carrier and note such damage on the carrier's freight bill of lading.
- D. Store materials in a dry place, indoors, on raised platform protected from weather damage.

PART 2 PRODUCTS

2.1 Manufacturers

- A. Acceptable manufacturer: Homasote Company, 932 Lower Ferry Road, West Trenton, N.J. 08628. Telephone: 800-257-9491 or 609-883-3300, Sales Department, Ext. 1500, Technical Support, Ext. 1332, Fax 609-883-3497. Web site: www.homasote.com. For a local Homasote Company sales rep call the Sales Department, Ext. 1500.
- B. Requests for substitutions will be considered in accordance with provisions of section 01600.
- C. Substitutions: not permitted.

- D. Provide all sound-deadening boards from a single manufacturer.

2.2 Materials

- A. Sound-deadening boards: Homasote 440 SoundBarrier®; physical properties as follows:
 - 1. Thickness: 1/2 inch (13mm), 5/8 inch (16mm), 3/4 inch (19mm).
 - 2. Density: 26-28 pcf (416-448 kg/cubic m).
 - 3. Tensile strength: 450-700 psi (3,100-4,830 kPa).
 - 4. Hardness (Janka Ball): 230 lbs. (104 kg).
 - 5. Water absorption by volume; ASTM C209:
 - a. 2 hour immersion: 7 percent maximum.
 - 6. Expansion, 50 to 90 percent relative humidity: 0.25 percent.
 - 7. R-value: 1/2 inch 1.2 (0.021), 5/8 inch 1.33, 3/4 inch 1.4.
 - 8. Flame spread: Class III (or C).
 - 9. Noise reduction coefficient: 0.20.

2.3 Accessories

- A. Adhesive: APA AFG-01 approved.
- B. Ringshank nails: length as required to penetrate a minimum of 3/4 inch (19mm) into framing.
- C. Screws:
 - 1. Coarse thread drywall type wood screw, length as required to penetrate 3/4 inch (19 mm) into framing.

PART 3 EXECUTION

3.1 Examination


- A. Examine substrates upon which work will be installed.
- B. Verify framing member spacing complies with manufacturer's requirements depending on substrates and installation methods.
- C. Verify environmental conditions are, and will continue to be, maintained in accordance with manufacturer's recommendations.
- D. Coordinate with responsible entity to perform corrective work on unsatisfactory substrates or conditions.
- E. Starting work by installer is acceptance of substrates and environmental conditions.

3.2 Preparation

- A. Follow manufacturer's instructions by separating and allowing Homasote 440 SoundBarrier® to be exposed to environmental temperature and humidity conditions for not less than 24 hours before start of installation.
- B. 440 SoundBarrier® panels must be installed in a clean, dry condition. DO NOT INSTALL WET PANELS. Vertical applications only. Not to be used as a roof sheathing. Panels must be kept a minimum of 8" above grade. 440 SoundBarrier® panels must be thoroughly dry prior to closing in the structure.

3.3 Installation

- A. Follow manufacturer's instructions for cutting and installation of Homasote 440 SoundBarrier®.
- B. Over walls: use 440 Sound Barrier®:
 - 1. Allow 3/16" (4.7mm) gap at panel joints, and 3/8" (9.5mm) space at floors, ceilings and inside corners.
 - 2. Allow 3/16" (4.7mm) gap at panel joints, and 3/8" (9.5mm) space at floors, ceilings and inside corners.
 - 3. Using ring-shank nails or wood/metal drywall screws; attach 12" o.c. along panel edges and 24" o.c. along all intermediate framing. Nails or screws must be of sufficient length to penetrate 3/4" (19mm) into framing.
 - 4. Apply 3/8" bead of adhesive to gypsum wall board that meets the specification APA AFG-01 (such as Liquid Nails or PL400) in single vertical serpentine beads that are in between the studs. Stagger gypsum drywall so edges do not fall onto studs. Using #10 x 1-1/2" bugle head screws, secure the gypsum drywall directly to the 440 SoundBarrier panels every 8" o.c. around panel edges and 12" o.c. on intermediate sections of the panel, missing the studs.



3.4 Adjusting and Cleaning

- A. Replace panels that cannot be repaired.

To make sure you have the most current installation instructions visit <http://www.Homasote.com/installation> to see if newer instructions are online. If online is newer, print out and use the Internet version. These instructions were printed April 11, 2013.

(800)257-9491 • Technical Support call Ext. 1332 or e-mail techhelp@homasote.com

www.homasote.com